

A pressure relief valve listed as complying with the standard for Relief Valve and Automatic Gas Shutoff Devices for Hot Water Supply Systems, ANSI Z21.22, shall be installed at the time of installation of the heater in the location specified by the manufacturer. Local codes shall govern the installation of relief devices for safety operation of the water heater. The relief valve must not be removed or plugged.

No valve shall be placed between the relief valve and the water heater. The relief from the discharge of the pressure relief valve shall be disposed of in a suitable place where it will cause no damage. Also there shall be no other reducing coupling or other restrictions installed on the discharge line to restrict flow.

See Installation Manual Heading "PRESSURE RELIEF VALVES" for installation and maintenance of relief valve discharge line and other safety precaution.

Do not install this water heater under an overhang less than 2 ft from top of water heater when install at outside. The area under the overhang must be open on 3 sides.

Minimum Clearances from Combustible or Non-combustible Construction		
Clearance	Outdoor Install	Indoor Install
Top of heater	36 inches	12 inches
Back of heater	1 inch	1 inch
Front of heater	24 inches	24 inches
Side of heater	2 inches	2 inches
Bottom of heater	12 inches	6 inches

**FOR YOUR SAFETY READ BEFORE INSTALLATION**

**WARNING: If you do not follow these instructions exactly, a fire or explosion may result causing property damage, personal injury or loss of life.**

A. This appliance does not have a pilot. It is equipped with an ignition device which automatically lights the burner. Do not try to light the burner by hand.

B. BEFORE OPERATING smell all around the appliance area for gas. Be sure to smell next to the floor because some gas is heavier than air and will settle on the floor.

**WHAT TO DO IF YOU SMELL GAS**

- Do not try to light any appliance.
- Do not touch any electric switch; do not use any phone in your building.
- Immediately call your gas supplier from a neighbor's phone. Follow the gas supplier's instructions.
- If you cannot reach your gas supplier, call the fire department.

C. Use only your hand to push in or turn the gas control knob. Never use tools. If the knob will not push in or turn by hand, don't try to repair it; call a qualified service technician. Force or attempted repair may result in a fire or explosion.

D. Do not use this appliance if any part has been under water. Immediately call a qualified service technician to inspect the appliance and to replace any part of the control system and any gas control which has been underwater.

**OPERATING INSTRUCTIONS**

STOP! Read the safety information above on this label.

- Turn off all electric power to the appliance.
- Do not attempt to light the burner by hand.
- Turn the gas control manual valve located on the outside of the unit counterclockwise to the off position.
- Wait a few minutes to clear out any gas. If you then smell gas, STOP! Follow "B" in the safety information above on this label. If you don't smell gas, go to the next step.
- Turn the gas control manual valve located on the outside of the unit clockwise to the ON position.
- Turn on all electrical power to the appliance.
- If the appliance will not operate, follow the instructions "To Turn Off

**DANGER**

Vapors from flammable liquids will explode and catch fire causing death or severe burns. Do not use or store flammable products such as gasoline, solvents or adhesives in the same room or area near the water heater.

Keep flammable products:

- Far away from heater.
- In approved containers.
- Tightly closed and out of reach of children.
- Water heater has a main burner, which may come on at any time and will ignite flammable vapors.

Installation: Do not install water heater where flammable products will be stored or used unless the main burner are at least 18" above the floor. This will reduce, but not eliminate the risk of vapors being ignited by the main burner.

Read and follow water heater warnings and instructions. If the owner's manual is missing, contact the retailer or manufacturer.

**DANGER**

- Water temperature over 125°F can cause severe burns instantly or death from scalds.
- Children, disabled and elderly are at highest risk of being scalded.
- Test water before bathing or showering.
- Temperature limit valves are available, see manual.

**WARNING**

The outlet temperature of the water heater is set at 122°F (50°C). If you require water temperature below this setting, follow the instruction manual.

Use the heater at your own risk. The set outlet water temperature can cause severe burns instantly or death from scalds. Test the water before bathing or showering. Do not leave children or an infirm person unattended. See your local water supply company (plumbing hardware retailer) for temperature limiting valves that are available.

**WARNING**

\$199,900

## 601 GLENWAY AVENUE, KNOXVILLE, IL, 61448

<https://rhoadesrealtors.com>

Completely renovated in 2025, this beautiful 3 bed, 2 full bath home is ready for you to simply move in and unpack your boxes! From a new roof & siding to new plumbing & heating, this property has been thoughtfully updated throughout. The open concept kitchen and informal dining area features brand new appliances, butcher [...]

- 3 beds
- 2 baths
- Residential
- Single Family Residence
- Active
- 1320 sq ft

## Rooms



Room type	Area	Level	Length	Width
Main Level	1320			
Upper Level				
Lower Level				
Basement				
Additional Level				
Bedroom 1		Main	19.4	10.1
Bedroom 2		Main	12.2	7.5
Bedroom 3		Main	9.5	8.5
Living Room		Main	19.4	12.7
Dining Room		Main	16.5	9.5
Kitchen		Main	13.5	9.5
Laundry		Main	10.9	6.6

Third Floor

## Building Details



**ArchitecturalStyle:** Ranch

**Heating:** Natural Gas, Forced Air

**Exterior material:** Frame, Vinyl Siding

**Parking:** Attached

**NewConstructionYN:** No

**Basement:** Crawl Space

**Roof:** Shingle

---

## Amenities & Features

**Waterfront available:** No

**AttachedGarageYN:** No

**PoolPrivateYN:** No

**ExteriorFeatures:** Replacement Windows

**Features:** Solid Surface Counter

**GarageYN:** Yes

**FireplaceYN:** No

**Cooling:** Central Air

**Amenities:** Dishwasher, Microwave, Range, Refrigerator

